



NCT1

MDU1

LF1

HS2

FA

1

2

3

LF3

129

27

26

EC2

CY2

+

USB2

USB3

USB4

USB5

USB6

AC

TX0

LF2

DX0

B11

B10

C4

B1

C3

D3

R3

R2

C2

R1

R8

R5

D4

D1

R6

R4

R3

C1

R2

R1

R12

R11

R10

R9

R8

R7

R6

R5

R4

R3

R2

R1

R18

R17

R16

R15

R14

R13

R12

R11

R10

R9

R8

EC1

CS

D5

EC6

CY1

T1

R29

R28

R27

R26

R25

R24

R23

R22

R21

DB1

HS1

R27

+

+

+

+

+

+

+

+

+

+

+

LED1

R15