



hange history:
VerC6 to C7
1: Add bead to G of Q1 MOSFET
2: move FR4 bead to Source of Q1MOSFET from Drain.
VerC5 to C6